



CJ1W-SCU42

Serial high-speed communication unit, 1x RS-232C port + 1x RS-422/485 port, Protocol Macro, Host Link, 1:N NT Link, No protocol, Serial Gateway (CompoWay/F, MODBUS-RTU, MODBUS-ASCII, Host Link), MODBUS RTU Slave, up to 230 kbps

Specifications

I/O system	CJ I/O Bus
Expansion unit type	CPU Bus Unit
Type of module	Communication
IO-Link master	✗
Communication port(s)	MODBUS Master, MODBUS Slave, Serial RS-232C, Serial RS-422, Serial RS-485
Number of communication ports	2
Max. data rate	230 kBit/s
Product Height (unpacked)	90 mm
Product Width (unpacked)	31 mm
Product Depth (unpacked)	81.9 mm
Product Weight (unpacked)	190 g

Downloads

CAD Library



CJ Series Serial Communications Unit for NJ Series
Operation Manual

EN PDF 4.55 MB



CJ-series -[RS-232C]-MARS TOHKEN SOLUTION MVF-300/500-series
Connection Guide

EN PDF 1.93 MB



CJ-series -[RS-232C]-MARS TOHKEN TFIR-31LAN-series
Connection Guide

EN PDF 2.42 MB



CJ-series -[RS-232C]-Shimadzu balance (ATX-R/ATY-R/UPX/UPY/UW/UX Series)
Connection Guide

EN PDF 2.34 MB



CJ-series -[RS-232C]-V400-R2-series Ultra Small Multi-code Reader
Connection Guide

EN ZIP 2.55 MB



CJ-series -[RS-232C]-V500-R2-series Fixed Laser-Type Barcode Reader
Connection Guide

EN ZIP 2.62 MB



CJ-series -[RS-232C]- V750-series RFID System

Connection Guide

EN ZIP 1.94 MB



CJ-series -[RS-232C]- ZW-7000-series Displacement Sensor

Connection Guide

EN ZIP 1.95 MB



CJ-series -[RS-485 CompoWay/F]- Digital Temperature Controller (E5xD/E5xC/E5xC-T)

Connection Guide

EN PDF 3.3 MB



CJ-series -[RS-485 CompoWay/F]- KM50 Smart Power Monitor

Connection Guide

EN ZIP 2.82 MB



CJ-series -[RS-485 Modbus]- 3G3MX2- series Type V1

Connection Guide

EN ZIP 2.33 MB



CJ-series -[RS-485 Modbus]- ORIENTAL MOTOR Alpha STEP AR- series

Connection Guide

EN ZIP 3.02 MB



CJ-series -[RS-485 Modbus]- ORIENTAL MOTOR Alpha STEP AZ- series

Connection Guide

EN ZIP 2.98 MB



CJ-series -[RS-485 Modbus]- ORIENTAL MOTOR BLE-series Brushless Motor

Connection Guide

EN ZIP 2.58 MB



CJ-series -[RS-485 Modbus]- ORIENTAL MOTOR RK II-series Stepping Motor

Connection Guide

EN ZIP 3.79 MB



CJ1W-SCU Serial Communications Units Datasheet

EN PDF 1.32 MB



CJ2-Series Programmable Controller Datasheet

EN PDF 17.9 MB



CP1 Series Brochure

EN PDF 3.11 MB



CS1 / CJ1 Serial Communications Boards

Operation Manual

EN PDF 5.88 MB



CompoNet Leaflet

EN PDF 13 MB



DeviceNet Brochure

EN PDF 471 KB



EAC Mark removal Discontinuation Notice

EN PDF 221 KB



NJ-series -[RS-232C]- G9SP Safety Controller

Connection Guide

EN ZIP 4.5 MB



NJ-series -[RS-232C]- V400-R2-series Ultra Small Multi-code Reader

Connection Guide

EN ZIP 4.64 MB



NJ-series -[RS-232C]- V500-R2-series Fixed Laser-Type Barcode Reader

Connection Guide

EN ZIP 4.71 MB



NJ-series -[RS-232C]- V750-series RFID System

Connection Guide

EN ZIP 5.11 MB



NJ-series -[RS-232C]- ZW-series Displacement Sensor

Connection Guide

EN ZIP 4.68 MB



NJ-series -[RS-485 CompoWay/F]- E5CC/E5EC/E5AC Digital Controller

Connection Guide

EN ZIP 4.71 MB



NJ-series -[RS-485 CompoWay/F]- KM1/KE1-series

Connection Guide

EN ZIP 5.4 MB



NJ-series -[RS-485 Modbus]- ORIENTAL MOTOR Alpha STEP AR- series

Connection Guide

EN ZIP 2.83 MB



**NJ-series -[RS-485
Modbus]- ORIENTAL
MOTOR Alpha STEP AZ-
series**

Connection Guide

EN ZIP 3.01 MB



**NJ-series -[RS-485
Modbus]- ORIENTAL
MOTOR BLE-series
Brushless Motor**

Connection Guide

EN ZIP 2.67 MB



**NJ-series -[RS-485
Modbus]- ORIENTAL
MOTOR RK II-series
Stepping Motor**

Connection Guide

EN ZIP 5.5 MB