

789/787B

ProcessMeter™

Quick Reference Guide


∧ ∧ Warning

To prevent possible electrical shock, fire, or personal injury, read the "789/787B Safety Information" before you use this Product.


(i) Consult user documentation.


Go to www.fluke.com to register your product and find more information.


$\widetilde{\mathsf{v}} = \overline{\mathsf{m}}$




PN 4276679 August 2012, Rev. 1, 1/17 © 2012-2017 Fluke Corporation. All rights reserved.
















2


OL


0





Output Source Output Simulate





Supplying Loop Power (789 only)

